

FARM KING ALLIED INC.

A John Buhler Company

1988 OPERATORS MANUAL PORTABLE AUGERS

FARM KING PRODUCTS

301 Mountain Avenue
Box 1450 R0G 1J0
Morden, MB, Canada
(204) 822-4467

ALLIED PRODUCTS

1201 Regent Avenue W.
Box 1003 R3C 2W5
Winnipeg, MB, Canada
(204) 661-8711



**THIS SAFETY ALERT SYMBOL MEANS:
ATTENTION!
BE ALERT!
YOUR SAFETY IS INVOLVED!**



*Your safety is in
your hands*

1988

OPERATORS MANUAL

PORTABLE AUGERS

OPERATING INSTRUCTIONS

All augers may be elevated up to 45 degrees; however, for best operating efficiency, 35 degrees should not be exceeded. At angles over 35 degrees the capacity and life of the auger decreases.

Never operate an empty auger for over one minute as the flighting and housing will experience excessive wear.

To position the auger, always tow or move the auger in the down position to a point as close as possible to the bin or barn.

! CAUTION: Always keep the wheels level. Raise the auger to the desired height and back the auger into position. Rest the head on some support. As an auger is emptied the head becomes heavy, the tail becomes light, and the auger could tip.

! CAUTION: Never place blocks under the wheels to increase the elevation of the auger.

Be sure the wheels are free to move and no one is standing close to the auger when raising or lowering. Never attempt to raise or lower the auger while it is in operation.

The auger is equipped with a safety brakewinch. The auger may be raised or lowered by simply turning the winch handle in the proper direction until the desired discharge height is obtained.

Never have less than three wraps of cable on the drum of the winch.

! CAUTION: All wiring should be done by a competent electrical contractor to assure the motor is receiving the correct voltage and the cable will carry the correct load.

The life of a motor is greatly reduced if it is run at too high or too low voltage. Also, a motor cannot develop full power if the cable is too small. The electrical supply to each motor should include an enclosed safety switch or circuit breaker of the correct size to protect the motor from being overloaded. The switch should be under a padlock to prevent the motor from being turned on by accident while working on or moving the auger. This will also prevent unauthorized persons or children from operating the motor. A magnetic starter should be used to shut off the motor in case of low voltage, loss of power, or overloading the motor.

The motor must then be started manually.

Power Take-Off drives are designed for tractors with 540 RPM power take-off and should not be run by tractors with 1000 RPM power take-off.

To assure a long life from a tumbler shaft, operate the shaft at the least angle possible and always keep the tractor axle parallel to the side of the auger housing.

! CAUTION: Always maintain at least a 6" lap on the tumbler shields. Be sure they turn freely and make certain everyone stands clear of tractor, tumbler shaft, and auger before engaging power take-off. Be sure ends are securely connected to the auger and tractor.

Vol. 41, No. 1, January 1, 1929
Published by the American Medical Association, 535 North Dearborn Street, Chicago, Ill.
Subscription price, \$5.00 per annum in advance. Single copies, 15 cents.

Entered as Second-Class Matter, June 26, 1925, Post Office at Chicago, Ill., under No. 102,362.
Acceptance for mailing at special rate of postage provided for in Act of October 3, 1917, authorized on July 1, 1928.

Postage paid at Chicago, Ill., and at additional mailing offices.
Postmaster: Send address changes in Chicago, Ill., to THE JOURNAL OF THE AMERICAN MEDICAL ASSOCIATION, 535 North Dearborn Street, Chicago, Ill. 41.

Copyright, 1929, by American Medical Association
All rights reserved. Reproduction by any means without permission is prohibited.
Printed at the Chicago Press, Chicago, Ill.

Published by the American Medical Association, 535 North Dearborn Street, Chicago, Ill.
Subscription price, \$5.00 per annum in advance. Single copies, 15 cents.

Entered as Second-Class Matter, June 26, 1925, Post Office at Chicago, Ill., under No. 102,362.
Acceptance for mailing at special rate of postage provided for in Act of October 3, 1917, authorized on July 1, 1928.

Postage paid at Chicago, Ill., and at additional mailing offices.
Postmaster: Send address changes in Chicago, Ill., to THE JOURNAL OF THE AMERICAN MEDICAL ASSOCIATION, 535 North Dearborn Street, Chicago, Ill. 41.

Published by the American Medical Association, 535 North Dearborn Street, Chicago, Ill.
Subscription price, \$5.00 per annum in advance. Single copies, 15 cents.

Entered as Second-Class Matter, June 26, 1925, Post Office at Chicago, Ill., under No. 102,362.
Acceptance for mailing at special rate of postage provided for in Act of October 3, 1917, authorized on July 1, 1928.

Postage paid at Chicago, Ill., and at additional mailing offices.
Postmaster: Send address changes in Chicago, Ill., to THE JOURNAL OF THE AMERICAN MEDICAL ASSOCIATION, 535 North Dearborn Street, Chicago, Ill. 41.

Published by the American Medical Association, 535 North Dearborn Street, Chicago, Ill.
Subscription price, \$5.00 per annum in advance. Single copies, 15 cents.

Entered as Second-Class Matter, June 26, 1925, Post Office at Chicago, Ill., under No. 102,362.
Acceptance for mailing at special rate of postage provided for in Act of October 3, 1917, authorized on July 1, 1928.

Postage paid at Chicago, Ill., and at additional mailing offices.
Postmaster: Send address changes in Chicago, Ill., to THE JOURNAL OF THE AMERICAN MEDICAL ASSOCIATION, 535 North Dearborn Street, Chicago, Ill. 41.

Published by the American Medical Association, 535 North Dearborn Street, Chicago, Ill.
Subscription price, \$5.00 per annum in advance. Single copies, 15 cents.

Entered as Second-Class Matter, June 26, 1925, Post Office at Chicago, Ill., under No. 102,362.
Acceptance for mailing at special rate of postage provided for in Act of October 3, 1917, authorized on July 1, 1928.

Postage paid at Chicago, Ill., and at additional mailing offices.
Postmaster: Send address changes in Chicago, Ill., to THE JOURNAL OF THE AMERICAN MEDICAL ASSOCIATION, 535 North Dearborn Street, Chicago, Ill. 41.

Published by the American Medical Association, 535 North Dearborn Street, Chicago, Ill.
Subscription price, \$5.00 per annum in advance. Single copies, 15 cents.

Entered as Second-Class Matter, June 26, 1925, Post Office at Chicago, Ill., under No. 102,362.
Acceptance for mailing at special rate of postage provided for in Act of October 3, 1917, authorized on July 1, 1928.

Postage paid at Chicago, Ill., and at additional mailing offices.
Postmaster: Send address changes in Chicago, Ill., to THE JOURNAL OF THE AMERICAN MEDICAL ASSOCIATION, 535 North Dearborn Street, Chicago, Ill. 41.

SAFETY INSTRUCTIONS

The safety of the operator of any piece of equipment is of prime importance to the manufacturer and the following precautions should be taken when operating, starting or doing any maintenance work on this auger.

Always transport the auger in the down position carrying the weight of the auger on the winch cable and not on the transport stops.

When moving the auger on a road use red flag, or at night, if absolutely necessary, accessory lights for adequate warning to operators of other vehicles.

The auger must be on a level surface and the wheels free to move when raising or lowering. Everyone should be kept clear during these operations.

Never stand under the auger while raising or lowering.

When filling tall bins, tanks or granaries, it is advisable to anchor the auger to the bin or building to prevent it from being tipped over by the wind or a sudden movement. The upper end of auger should rest on some support when in operation.

Keep hands, feet and clothing away from exposed flighting and all moving parts. Do not allow children or anyone other than the operator close to the auger when in operation.

Before attempting to service, adjust or unclog an auger, disengage drive and shut off engine. In the case of an electric motor, shut off switch and unplug the connection.

Never operate an auger with the tail end off the ground.

When storing, the tail should be tied or weighted to prevent children or others from tipping the auger. The power source should be fixed in such a way that no one except an authorized person could start the unit.

Never raise the tail of an auger above waist high as the balance shifts forward and the auger will tip over.



CAUTION

1. Read and understand the Operator's Manual before operating.
2. Keep all safety shields and devices in place.
3. Make certain everyone is clear before operating or moving machine.
4. Keep hands, feet and clothing away from moving parts.
5. Shut off power to adjust, service or clean.
6. Support discharge end or anchor intake end to prevent upending.
7. Disconnect power before resetting motor overload.
8. Empty auger before moving, to prevent upending.
9. Lower auger to transport position for transporting.
10. Make certain electric motors are grounded.

Before engaging power take-off, start tractor and idle engine. Engage power take-off slowly and bring PTO RPM up to recommended speed of 500 RPM for 6", 7" & 8" augers.

Before stopping auger (except in an emergency) let all grain empty out of the auger, idle engine then disengage power take-off. Shut off tractor.

NOTE: When operating an auger for the first time when new or at the beginning of a season, run only partially full until flighting becomes polished. It is always a good idea to check the flighting for freedom of movement by turning pulley or tumbler shaft by hand before connecting to a power source. Other items to check are the head (spout) and intake cage for bird nests or other obstructions before starting the auger.

IMPORTANT: Always lower auger before transporting and allow the weight of the auger to rest on the winch cable and not on the transport stops.



CAUTION: When towing the auger, never exceed 20 miles per hour.

IMPORTANT: Do not install the clevis pin (No.70) in the back hole of the hitch (No.69) when towing as this will weaken the assembly.

Always use a flag, or at night, a signal light when towing an auger on a road. Check your local regulations for further safety devices in this regard.

MAINTENANCE & LUBRICATION

Check condition of winch cable occasionally and replace if it shows wear. The greatest wear will occur on the first few wraps around the drum of the winch.

Lubricate the tumbler shaft universal joints every five hours. Grease the PTO shear yoke before using PTO for the first time.

Oil the moving parts of the winch two times per year.

Check the oil level of the gearbox one time per year and maintain the level at $\frac{1}{2}$ full. Use SAE90.

STORAGE

The auger should be stored in a dry place if possible. If stored outside, lower auger to its lowest position and tie the tail end down so that no one can accidentally overturn it.

Clean auger thoroughly as dirt draws moisture and causes metal to rust. If the auger has been used to move fertilizer, clean thoroughly and apply oil or grease on entire flighting and inside the housing to stop and prevent further corrosion.

Remove belts and store in a cool dry place if auger is to be left outdoors.

At this time check all moving parts for wear and order replacement parts from your nearest dealer.

When taking the auger out of storage, clean it thoroughly and check for obstructions at the inlet and outlet ends. Check the oil in the gearbox.

Check all bolts and set screws.

WARRANTY

Farm King Ltd. warrants its products to be free from defect in factory workmanship and material under normal use and service, when set-up and operated according to factory instruction. Warranty should be handled through the authorized selling dealer or distributor. Warranty is subject to the following condition:

* WARRANTY CLAIMS:

Must be completed within 30 days of replacement of part or parts. Claim must include serial number of machine, date of delivery, and all other necessary particulars including part numbers and explanation of problem.

* WARRANTY PARTS:

Must be kept for Farm King inspection unless otherwise specified.

NOTE: Special 2-year parts warranty on augers manufactured in 1982 and later.

* WARRANTY LABOUR:

Any labour subject to warranty must be authorized by Farm King. Labour allowance will be handled according to established service policy.

* WARRANTY LIMITATIONS:

Warranty will not be granted on any machine that has been altered or modified in any way.

Warranty on P.T.O. shafts, cylinders, hubs, and other trade accessories are limited to the warranties made by the respective manufacturers. Tires and tubes are warranted directly by the manufacturer only and not Farm King.

* GOVERNMENT LEGISLATION

Warranty terms and conditions are subject to provincial or state legislation.

The first of these is the fact that the
government has been unable to secure
the necessary funds to carry out its
policy of expansion. This is due to the
fact that the government has been unable to
secure the necessary funds to carry out its
policy of expansion.

Conclusion

The second of these is the fact that the
government has been unable to secure
the necessary funds to carry out its
policy of expansion. This is due to the
fact that the government has been unable to
secure the necessary funds to carry out its
policy of expansion.

References

1. The first of these is the fact that the
government has been unable to secure
the necessary funds to carry out its
policy of expansion. This is due to the
fact that the government has been unable to
secure the necessary funds to carry out its
policy of expansion.

Notes

1. The first of these is the fact that the
government has been unable to secure
the necessary funds to carry out its
policy of expansion. This is due to the
fact that the government has been unable to
secure the necessary funds to carry out its
policy of expansion.

Appendix

1. The first of these is the fact that the
government has been unable to secure
the necessary funds to carry out its
policy of expansion. This is due to the
fact that the government has been unable to
secure the necessary funds to carry out its
policy of expansion.

2. The second of these is the fact that the
government has been unable to secure
the necessary funds to carry out its
policy of expansion. This is due to the
fact that the government has been unable to
secure the necessary funds to carry out its
policy of expansion.

Index

1. The first of these is the fact that the
government has been unable to secure
the necessary funds to carry out its
policy of expansion. This is due to the
fact that the government has been unable to
secure the necessary funds to carry out its
policy of expansion.

FARM KING PORTABLE GRAIN AUGER ASSEMBLY INSTRUCTIONS


1. Assemble the BASIC AUGER section #1 to the EXTENSION section #2 making sure the flighting is aligned and locked with a $\frac{3}{8}$ " x 2" Grade 8 cap screw and lock nut.

Use $\frac{3}{8}$ x 1 cap screws, lock washers and hex nuts to fasten the auger rings together. Align the two sections before tightening the bolts. be sure to tighten bolts evenly - first one side and then the other.

Attach the INTAKE ASSEMBLY #66 using $\frac{3}{8}$ x $1\frac{3}{4}$ cap screws, lock washers and hex nuts.

2. Connect the extension DRIVE LINE #9 to the basic drive line #8.
3. Attach COUPLER #56 to extension drive line #9 using $\frac{1}{4}$ x $\frac{1}{4}$ x $3\frac{1}{2}$ key and $\frac{3}{8}$ x $\frac{3}{8}$ socket set screw.

NOTE: The pinion shaft of the gearbox should protrude into the 4" coupler at least $1\frac{3}{4}$ " as shown in diagram.




4. Install GEARBOX #74 on mounting plate using $\frac{7}{16}$ x $\frac{3}{4}$ cap screws and lock washers.
5. Mount the two UNDERCARRIAGE ARMS #5A and #5B to gearbox. The #5A arm has a wider ring and goes on the pulley side of the gearbox. A TIE PLATE #5D is used to connect the arms. Use $\frac{3}{8}$ x 1 cap screws, lock washers and hex nuts. NOTE: Be sure the rings on the undercarriage arms are free and are lubricated so they will pivot properly.

Bolt the undercarriage arms to the AXLE #5C using $\frac{7}{16}$ x $1\frac{1}{4}$ cap screws, lock washers and hex nuts.

6. Fasten TRACK STOPS #25 as per illustration according to the length of auger. (Upper right hand corner of drawing #2)

7. Remove the larger cap screw from the track roller assembly and insert the assembly into the telescoping yoke (#10) so that the chain link points towards the auger intake end. NOTE: The larger cap screw must be locked with a jam nut.



8. Bolt the two LIFT ARMS #6A and #6B to the CENTER SLEEVE #6C using $\frac{3}{8}$ x $1\frac{1}{4}$ cap screws, lock washers and hex nuts on the sides of the sleeve and $\frac{1}{2}$ x 5 cap screws, lock washers and hex nuts to clamp the top end of the lift arms to the sleeve. Attach the lift arm assembly (with the TELESCOPING TUBE #10) to the undercarriage axle using $\frac{5}{8}$ x 2 cap screws, nuts and jam nuts.

FARM KING PORTABLE AUGER INSTRUCTIONS CONTINUED

9. Fasten WINCH #95 to lift arms #6 using 3/8" x 1" cap screws, lock washers and nuts. There is also a flat washer provided for the bolt in the slotted hole.
10. A) Insert cable #91 into loop on lift arm #10 using cable clamps and tighten.
B) Thread cable as per illustration. Fasten cable to winch spool using cable clamp supplied with the winch.
11. Mount WHEELS #104 on undercarriage using 1/2" wheel bolts.
12. Install HANGER #7 in undercarriage so that the upper flange with 2 holes is on pulley side of auger. Use 1/4 x 1 3/4 cotter pins and 1 1/4 flat washers.
13. A) ENGINE DRIVE AUGERS ONLY - lower left hand side of drawing #2.
 - a) MOTOR MOUNT #126 should be installed so the handle is toward the axle. Use 1/2 x 1 1/4 cap screws. Fasten BELT GUARD BRACKET #125 together with motor mount as per illustration.
 - b) The 12" PULLEY #121 is mounted on the gearbox #74 with 1/4 x 1 1/4 key, so that the long end of hub is toward the gearbox and short end is approximately flush with gearbox shaft.
 - c) Mount the LARGE BELT GUARD #119 over the 12" pulley and align end opening to the hanger.
 - d) Mount SMALL BELT GUARD # 124 on bracket #125 as shown.
 - e) Attach one end of LEVELLING ROD #118 to bracket (welded to auger tube below gearbox) using 1/2 x 1 1/2 cap screws & jam nuts. LEVELLING TUBE #116 fastens to hanger as per drawing.
 - f) The quick release on the motor mount is used when starting the engine and to stop the auger without shutting off the engine.
- B) PTO DRIVE AUGERS ONLY - lower right hand side of drawing #2.
 - a) Install PTO ARBOR ASSEMBLY #137 on hanger #7.
 - b) Attach the 12" PULLEY #121 to the PTO arbor using 1/4 x 1/4 x 1 1/2 key and set screw.
 - c) Mount the LARGE BELT GUARD #119 on the arbor ring.
 - d) Mount the 6" PULLEY on gearbox so the pulley is approximately flush with gearbox shaft. Fasten with 1/4" key and set screws.
 - e) Mount the belt(s) #122 on pulleys.
 - f) Attach the LEVELLING ROD #118 to the undercarriage bracket (under the pivot ring on pulley side). Attach the LEVELLING TUBE #116 to the hanger using 1/2 x 1 1/2 cap screws and jam nuts. Use this levelling rod to adjust the belt tension.
 - g) Mount the SMALL BELT GUARD #124 on the gearbox and adjust the alignment according to the belt(s).
 - h) Attach the PTO SHAFT #62 to arbor shaft #138.
 - i) Fasten PTO SHAFT CRADLE #97 onto the lift arms for transport position.
- C) DIRECT DRIVE AUGERS ONLY - drawing #1
 - a) For 1983, all direct drive augers use the same coupler #56 as the engine drive and PTO drive augers. The shear pin unit is on the PTO shaft.
NOTE: Shear pin for all augers is a 1/4" x 2" Grade 5 bolt. No other size or grade should be used.
 - b) Bolt PTO HANGER #64 to welded bracket on extension.
 - c) Attach PTO SHIELD #63 to gearbox.

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

THE UNIVERSITY OF CHICAGO
DEPARTMENT OF THE HISTORY OF ARTS
AND ARCHITECTURE

FARM KING PORTABLE AUGER INSTRUCTIONS CONTINUED

14. Recheck and tighten all bolts. Of particular importance are:



- CAUTION:
- 1) Cable clamps !!
 - 2) Jam nuts on track roller assembly
 - 3) Jam nuts on lift arms to undercarriage
 - 4) Tie plate bolts
 - 5) Gearbox mounting bolts
 - 6) Auger tube flanges
 - 7) Pulley set screws
 - 8) All shields
 - 9) Wheel bolts


15. Attach DRIVE LINE SHIELDS #30 starting at the top of auger. The last DRIVE LINE SHIELD #32 is bolted to the gearbox using 5/16 x 3/4 cap screw, lock washer and flat washer.


16. NOTE:
- 1) Gearbox is shipped without oil. Use 600 ml. of SAE 90.
 - 2) Do not exceed 600 RPM flighting speed when operating auger.
 - 3) An external chain tightener is supplied with 46' and 51' augers.



CAUTION

- 1) High Position: It is dangerous to move auger in raised position in vicinity of electrical lines.
- 2) Keep all shields and guards in place.
- 3) Turn off power when servicing or unplugging auger
- 4) Hitch pin clip must be securely in place when transporting auger.





AUGER PARTS LIST - 7" & 8"

<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1.	961955	Auger Tube, 7" X 22' Basic - 31', 36' & 41'
	961956	Auger Tube, 7" X 22' Basic - 46' & 51'
	961803	Auger Tube, 8" X 22' Basic - 41' Only
	961804	Auger Tube, 8" X 22' Basic - 46' & 51'
2.	961808	Auger Tube, 7" X 9' Extension
	961957	Auger Tube, 7" X 14' Extension
	961958	Auger Tube, 7" X 19' Extension
	961959	Auger Tube, 7" X 24' Extension
	961960	Auger Tube, 7" X 29' Extension
	961813	Auger Tube, 8" X 19' Extension
	961814	Auger Tube, 8" X 24' Extension
	961815	Auger Tube, 8" X 29' Extension
3.	961961	Auger Flighting, 7" X 22' Basic
	961725	Auger Flighting, 8" X 22' Basic
4.	961962	Auger Flighting, 7" X 9' Extension
	961963	Auger Flighting, 7" X 14' Extension
	961964	Auger Flighting, 7" X 19' Extension
	961965	Auger Flighting, 7" X 24' Extension
	961966	Auger Flighting, 7" X 29' Extension
	961726	Auger Flighting, 8" X 19' Extension
	961727	Auger Flighting, 8" X 24' Extension
	961728	Auger Flighting, 8" X 29' Extension
5.A	961401	9' L.H. Undercarriage Arm - 7" X 31' Augers
	961404	10'8" L.H. Undercarriage Arm - 7" X 36' Augers
	961407	12'3" L.H. Undercarriage Arm - 7" X 41' Augers
	961410	12'3" L.H. Undercarriage Arm - 8" X 41' Augers
	961412	13' L.H. Undercarriage Arm - 7" & 8" X 46' Augers
	961414	14'6" L.H. Undercarriage Arm - 7" & 8" X 51' Augers
5.B	961402	9' R.H. Undercarriage Arm - 7" X 31' Augers
	961405	10'8" R.H. Undercarriage Arm - 7" X 36' Augers
	961408	12'3" R.H. Undercarriage Arm - 7" X 41' Augers
	961411	12'3" R.H. Undercarriage Arm - 8" X 41' Augers
	961413	13' R.H. Undercarriage Arm - 7" X 8" X 46' Augers
	961415	14'6" R.H. Undercarriage Arm - 7" & 8" X 51' Augers
5.C	961403	2" X 66" Axle Assembly - 7" X 31' Augers
	961406	2" X 72" Axle Assembly - 7" X 36' Augers
	961409	2" X 78" Axle Assembly - 7" X 41' Augers
	961946	2 3/8" X 83" Axle Assembly - 8" X 41' Augers
	961974	2 3/8" X 83" Axle Assembly - 7" & 8" X 46' Augers
	961975	2 3/8" X 83" Axle Assembly - 7" & 8" X 51' Augers
5.D	961948	Undercarriage Tie Plate
6.A	961416	6' Left Hand Lift Arm - 7" X 31' Augers
	961418	7' Left Hand Lift Arm - 7" X 36' Augers
	961420	8'8" Left Hand Lift Arm - 7" X 41' Augers
	961422	8'8" Left Hand Lift Arm - 8" X 41' Augers
	961424	10'4" Left Hand Lift Arm - 7" & 8" X 46' Augers
	961427	12' Left Hand Lift Arm - 7" & 8" X 51' Augers
6.B	961417	6' Right Hand Lift Arm - 7" X 31' Augers
	961419	7' Right Hand Lift Arm - 7" X 36' Augers
	961421	8'8" Right Hand Lift Arm - 7" X 41' Augers
	961423	8'8" Right Hand Lift Arm - 8" X 41' Augers
	961425	10'4" Right Hand Lift Arm - 7" & 8" X 46' Augers
	961428	12' Right Hand Lift Arm - 7" & 8" X 51' Augers
6.C	961949	12" Lift Arm Center Sleeve - 7" X 31' & 36' Augers
	961426	15" Lift Arm Center Sleeve - 7" & 8" X 46' Augers
	961429	18" Lift Arm Center Sleeve - 7" & 8" X 51' Augers
	961438	12" Lift Arm Center Sleeve - 7" & 8" X 41'

AUGER PARTS LIST - 7" & 8" - CONTINUED

<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
7.	961829	36 1/2" Motor Mount Hanger - 31' & 36' Augers
	961830	44" Motor Mount Hanger - 41' & 46' Augers
	961831	51" Motor Mount Hanger - 51' Augers
8.	961732	Basic Drive Line - 7" & 8" Augers
9.	961967	Extension Drive Line - 7" X 31' Augers (5 1/2")
	961968	Extension Drive Line - 7" X 36' Augers (62 3/4")
	961836	Extension Drive Line - 8" X 41' D.D. Augers (148 1/2")
	961837	Extension Drive Line - 8" X 46' D.D. Augers (212")
	961838	Extension Drive Line - 8" X 51' D.D. Augers (272")
	961839	Extension Drive Line - 7" X 41' & 8" X 41' B.D. P.A. (101 1/2")
	961840	Extension Drive Line - 7" X 46' & 8" X 46' B.D. P.A. (130 1/4")
	961841	Extension Drive Line - 7" X 51' & 8" X 51' B.D. P.A. (173 1/4")
10.	961765	5' Telescoping Tube - 7" X 31' Augers
	961766	6' Telescoping Tube - 7" X 36' Augers
	961767	7' Telescoping Tube - 7" & 8" X 41' Augers
	961768	8' Telescoping Tube - 7" & 8" X 46' Augers
	961769	10' Telescoping Tube - 7" & 8" X 51' Augers
13.		7/16" X 3 1/2" Plated Cap Screw - 7" Augers
		7/16" X 4" Plated Cap Screw - 8" Augers
14.		7/16" Plated Hex Nut
15.		7/16" Plated Lockwasher
16.		7/16" Flatwasher
17.		5/8" X 5 1/2" Hex Head Bolt
18.	961573	Left Side Plate - '79 & Up
	961574	Right Side Plate - '79 & Up
19.	961624	Roller Assembly Spacer
20.	961844	Track Roller
21.	961845	Cable Pulley, 1" Bore
22.	961846	Cable Pulley, 1/2" Bore
23.		5/8" Jam Nut
24.		7" Flex Spout
		8" Flex Spout
25.	961770	Track Stop
26.		5/16" Lock Nut - '79 & Up
27.		3/8" Hex Nut
28.	961751	Bridging Rod Mounting Bracket (7" & 8" X 46' & 51') (Right)
	961752	Bridging Rod Mounting Bracket (7" & 8" X 46' & 51') (Left)
29.	961786	Bridging Rod (7" & 8" X 46' & 51')
30.	961848	66" Drive Line Shield - 7" & 8" Augers
31.	961787	Dummy Mounting Box - 8" Direct Drive Only
32.	961969	Extension Shield - 7" X 31' Augers
	961970	Extension Shield - 7" X 36' Augers
	961854	Extension Shield - 8" X 41' D.D. Augers
	961855	Extension Shield - 7" X 41' & 8" X 41' B.D. Augers
	961856	Extension Shield - 8" X 46' D.D. Augers
	961857	Extension Shield - 7" X 46' & 8" X 46' B.D.
	961858	Extension Shield - 8" X 51' D.D. Augers
	961859	Extension Shield - 7" X 51' & 8" X 51' B.D. Augers
33.	961644	Chain Guard - 7" & 8" Augers
34.		1/4" x 3/4" Cap Screw
35.		1/4" Hex Nut
36.		1/4" Lockwasher
37.		1/4" X 1 1/4" Key
38.	961860	#60 Roller Chain, 40 1/2L - 7" Augers
	961953	#60 Roller Chain, 36 L - 8" Augers (Two - 15 T Sprockets)
	961954	#60 Roller Chain, 42 1/2L - 8" Augers (One 15T & One 28T Sprocket)

AUGER PARTS LIST - 7" & 8" - CONTINUED

<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
39.	961684	15 Tooth Sprocket, #60, 1 1/4" Bore - 7" & 8" Augers
40.	961684	15 Tooth Sprocket, #60, 1 1/4" Bore - 8" D.D. Augers
	961686	28 Tooth Sprocket, #60, 1 1/4" Bore - 7" & 8" B.D. Augers
41.	961742	Top Bearing Retainer/Pair - 7" & 8" Augers
42.	961675	Bottom Bearing Retainer/Pair - 7" & 8" Augers
43.	961676	1 1/4" Bearing - 7" & 8" Augers
44.		3/8" x 1" Carriage Bolt
45.		3/8" x 1" Cap Screw
46.	961741	Auger End Plate - 7" X 31', 36', 7" & 8" X 41'
	961971	Auger End Plate - 7" & 8" X 46' & 51'
47.		3/8" Flatwasher
48.		3/8" Lockwasher
49.		5/16" x 3/4" Cap Screw
50.		5/16" Lockwasher
51.		5/16" Hex Nut
53.	965818	1 1/4" Bearing (206) - 7" & 8" Augers
54.		1 1/4" Bearing Collar
55.	961430	Bearing Holder 7" & 8" Augers
	961432	Bearing Holder Cap - 7" & 8" Augers
56.	961611	Drive Shaft Coupling With Set Screws
57.		1/4" x 3 1/2" Key
61.		5/16" x 3/4" Cap Screw
62.	F0053	Universal PTO Shaft
63.	961868	PTO Guard - 8" Direct Drive Only
64.A	961790	PTO Holder - 8" X 41' & 46' Direct Drive Only
64.B	961791	PTO Holder - 8" X 51' Direct Drive
65.		7/16" x 3/4" Plated Cap Screw
66.	961870	Intake Guard - 7" Augers
	961871	Intake Guard - 8" Augers
67.	961873	Intake Guard Clamp - 7" Augers
	961874	Intake Guard Clamp - 8" Augers
68.		3/8" x 1 3/4" Cap Screw
69.	961875	Hitch Clevis
70.	961876	1/2" X 1" Clevis Pin
71.	961877	Spring Clip
72.	961627	Bearing - 7" & 8" Augers
73.		1" Bearing Collar
74.	961878	Gearbox Assembly
75.	961879	Gearbox Casting Only
76.	961880	Gearbox Cross Shaft
76.A	961881	Pinion Shaft
77.	961882	Bevel Gear - 1 1/4" Bore
78.		Woodruff Key
79.		Roll Pin - 1/4" x 2" (On Earlier Models Only)
80.	961572	30MM Bearing
81.	961619	Oil Seal
82.	961883	Dust Cap
83.	961884	Small Snap Ring
83.A	961941	Small Snap Ring - '79
84.	961885	Large Snap Ring

AUGER PARTS LIST - 7" & 8" - CONTINUED

<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
85.	961886	Gearbox Cover
86.	961887	Gearbox Cover Gasket
87.	FBU500167-1	Gearbox Vent Plug
88.		1/2" X 2" Clevis Pin
89.		1/8" X 1" Collar Pin
90.	961658	1/4" Cable Clamp - 7" Augers
	961763	5/16" Cable Clamp - 7" X 51' & All 8" Augers
91.	961756	Cable - 7" X 31' Augers
	961757	Cable - 7" X 36' Augers
	961758	Cable - 7" X 41' Augers
	961760	Cable - 8" X 41' Augers
	961761	Cable - 7" & 8" X 46' Augers
	961762	Cable - 7" & 8" X 51' Augers
92.		5/8" x 2" Plated Cap Screws
93.		1 1/4" Flatwasher
94.		1/4" X 1 3/4" Cotter Pin
95.	961888	Winch Assembly - 7" X 31', 36', 41' & 46' Augers
	961945	Winch Assembly - 7" X 51' & All 8" Augers - '79 & Up
96.		3/8" x 2" Cap Screws
97.	961889	PTO Holder - 7" & 8" Belt Drive PTO Augers
98.	961890	PTO Holder Clamp
99.	961891	Oil Seal
100.	967712	Inner Bearing Cone
101.	967711	Inner Bearing Cup
102.	F105173	Hub Complete With Bearing Cups - 4 Bolt
103.	968404	1/2" Wheel Bolt
104.	961750	15" X 4.5" X 4 Bolt Wheel
105.	968405	Outer Bearing Cup
106.	968406	Outer Bearing Cone
107.		Washer
108.	968407	3/4" Slotted Hex Nut
109.		1/8" X 1 1/2" Cotter Pin
110.	968409	Dust Cap
111.	961892	Bearing Spacer
112.		1/4" Flatwasher
113.		5/16" X 1 1/4" Cap Screw
114.		1/2" X 2" Plated Cap Screw
115.		1/2" Jam Nut
116.	961645	Motor Mount Levelling Tube (All 7" & 8")
117.	961647	Levelling Tube Screw
118.	961646	Motor Mount Levelling Rod, 34" - 31' & 36' Augers
	961893	Motor Mount Levelling Rod, 60" - 41' & 46' Augers
	961894	Motor Mount Levelling Rod, 80" - 51' Augers
119.	961895	12" Pulley Guard
120.	961896	Pulley Guard Clamp (6")
120.A	961440	12" Pulley Guard Clamp
121.	961606	12" Single Pulley, 1" Bore - 7" X 31' Augers
	961567	12" Double Pulley, 1" Bore
122.	961771	B-158 Belt - 31' & 36' Augers
	961897	B-199 Belt - 41' & 46' Augers
	961898	B-255 Belt - 51' Augers
123.	961793	3 1/2" Single Pulley, 1" Bore - 7" X 31' Augers
	961899	3" Double Pulley, 1" Bore (See Whole Goods List)
124.	961900	6" Pulley Guard

AUGER PARTS LIST - 7" & 8" - CONTINUED

<u>ITEM</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
125.	961901	Guard Mounting Bracket
126.	961972	Motor Mount Complete
127.	961973	Motor Mount Adjusting Bolt
128.		3/4" Flatwasher
129.		3/16" X 1 1/4" Cotter Pin
130.	961558	7" Connecting Ring
	961559	8" Connecting Ring
131.	961902	6" Pulley Guard Insert - Belt Drive PTO
132.	961794	6" Double Pulley, 1" Bore
133.		1/4" X 2" Key
134.		1/2" X 1 1/2" Plated Cap Screw
135.		1/2" Plated Lockwasher
136.		1/2" Plated Hex Nut
137.	961903	PTO Mounting Plate - 31' & 36' Augers
	961904	PTO Mounting Plate - 41' & 46' Augers
	961905	PTO Mounting Plate - 51' Augers
138.	961906	14" Arbor Shaft - 31' & 36' Augers
	961907	19" Arbor Shaft - 41' & 46' Augers
	961908	23" Arbor Shaft - 51' Augers
139.	961909	Arbor Shield - 31' & 36' Augers
	961910	Arbor Shield - 41' & 46' Augers
	961911	Arbor Shield - 51' Augers
141.	961792	1" Pillow Bearing
142.	961913	1" Bearing Holder Cap
188.	961942	1/2" X 4 1/2" Cap Screw (Plated)
189.	F81966	1/2" Lock Nut
190.	961944	Cable Anchor
191.		3/8" X 1 1/4" Cap Screw (Plated)
192.		1/2" X 5" Cap Screw (Plated)
193.		7/16" X 1 1/4" Cap Screw (Plated)
194.	961952	Chain Tightener - 7" & 8" X 46' & 51' Augers
195.	961951	3/8" X 2" Sq. Hd. Set Screw
196.		3/8" Lock Nut
197.	961652	30MM Sealed Bearing

*SPECIAL OPEN END INTAKES C/W CLAMP:

7" INTAKE


8" INTAKE

NO. K1550 PARTS LIST - 1984 & UP

961888 - 7" & 8" X 31' AUGERS

<u>ITEM NO.</u>	<u>PART NAME</u>	<u>PART NO.</u>	
1.	HANDLE ASSEMBLY	2461S01	
2.	CABLE CLAMP		
3.	LOCKWASHER & NUT	CABLE KEEPER KIT	5621S01
4.	CARRIAGE BOLT		
5.	5/16" LOCK NUT	RATCHET KIT	6730S00
6.	RATCHET SPACER		
7.	RATCHET SPRING		
8.	RATCHET PAWL		
9.	SHOULDER BOLT		
11.	BRAKE DISC KIT		1558S00
12.	INPUT SHAFT	INPUT SHAFT KIT	1563S01
13.	1/2" LOCK NUT		
14.	SPACER		
15.	BUSHING		
16.	SHAFT BRAKE DISC		
17.	RATCHET GEAR		
18.	PINION & DISC ASSEMBLY		
19.	1/2" LOCK NUT		::
20.	DRUM ASSEMBLY		::
21.	FRAME		::
22.	1/2" X 5 3/4" CAP SCREW		::
23.	DRUM SPACER		::
24.	3/8" X 5 3/4" CAP SCREW		::
25.	FRAME SPACER		::
26.	3/8" LOCK NUT		::

:: NOT AVAILABLE



NO. K2550 PARTS LIST

961945 - ALL 8" AUGERS & 7" X 51' AUGERS - 1984 & UP

ITEM	PART NAME	PART NO.
1.	HANDLE	2461S01
4.	BOLT	
5.	CABLE CLAMP	
6.	LOCKWASHER	
7.	NUT	
8.	INPUT SHAFT	
9.	RETAINING RING	
10.	BRAKE DISC	
11.	RATCHET GEAR	
12.	PINION GEAR	
13.	BUSHING	
14.	INSERT	
15.	SPACER	
16.	NUT	
17.	FRICITION DISC	
18.	BUSHING	
19.	INSERT	
20.	INSERT	
21.	BUSHING	
22.	WASHER	
23.	INTERMEDIATE SHAFT	
24.	ROLL PIN	
25.	WOODRUFF KEY	
26.	GEAR	
27.	NUT	
28.	SPACER	
29.	RATCHET PAWL	
30.	SPRING	
31.	SHOULDER BOLT	
42.	DRUM BOLT	
43.	LOCK NUT	
44.	DRUM SPACER	
45.	DRUM ASSEMBLY	
46.	LOCK NUT	
47.	FRAME SPACER	
48.	BOLT	
49.	FRAME	


CABLE KEEPER KIT

INPUT SHAFT KIT

INTERMEDIATE SHAFT KIT


RATCHET KIT

* NOT AVAILABLE




INSTRUCTIONS FOR CONVERSION OF 8" DIRECT DRIVE TO BELT DRIVE PTO

1.
 - a) Remove extension drive line no. 9 and extension drive line shields no. 30 and 32. Mount the shorter belt drive line.
 - b) The dummy mounting box no. 31 is removed and the gearbox no. 74 is installed on this mounting plate using 7/16" x 3/4" capscrews.
 - c) Fasten undercarriage no. 5 to gearbox.
2. Attach coupler no. 56 to extension drive line no. 9 using 1/4 x 1/4 x 3 1/2 key and 3/8 x 3/8 socket set screw.
NOTE: Shear pin unit not required for belt drive augers.
3. Replace the lower 15 tooth sprocket no. 40 in the top drive unit with a 28 tooth sprocket supplied in kit.
4.
 - a) Install PTO arbor assembly no. 137 onto hanger no. 7.
 - b) Attach the 12" pulley no. 121 onto the PTO arbor using 1/4 x 1/4 x 1 1/2 key and set screws.
 - c) Mount the large belt guard no. 119 on the arbor ring.
 - d) Mount the 6" pulley no. 132 on gearbox so that the pulley is approximately flush with the gearbox shaft. Fasten with key and set screws.
 - e) Mount the belts no. 122.
 - f) Attach the leveling rod no. 118 to the undercarriage bracket (at the bend) and to the hanger, using 1/2 x 1 1/2 cap screws and jam nuts. Use this rod to adjust the belt tension.
 - g) Mount the small belt guard no. 124 on the gearbox and adjust the alignment according to belt.
 - h) Attach PTO shaft no. 62.
 - i) Fasten PTO shaft cradle no. 97 onto the lift arms for transport position.
5. Recheck and tighten all bolts.
6. Attach drive line shields no. 30 and 32.



BELT PTO DRIVE KIT INSTRUCTIONS

ITEM	PART NO.	DESCRIPTION
	FO053	SHAFT COMPLETE
	936148	TRACTOR HALF OF PTO
	936149	IMPLEMENT HALF OF PTO
	936164	SHEAR ASSEMBLY (#'S 9-14 INCLUSIVE)
1.	936073	ROUND HOLE YOKE
2.	936165	YOKE & TUBE ASSEMBLY
3.	936075	YOKE & BAR ASSEMBLY
4.	936152	INNER SHIELD
5.	936153	OUTER SHIELD
6.	936111	SHIELD BEARING KIT (2 PCS.)
7.	936124	SHIELD BEARING (1 PC.)
8.	936079	REPAIR KIT
9.	936154	SHEAR YOKE
10.	936155	SHEAR YOKE HUB
11.	936115	STEEL BALL (25/SET)
12.	936116	GREASE FITTING
13.		SHEAR BOLT - 1/4" X 2 1/4" (GRADE 5)
14.		1/4" LOCK NUT



KITS AVAILABLE

F0050	GAS, ELECTRIC ENGINE DRIVE
F0053	25 H.P. SAFETY P.T.O. SHAFT
F7063	BELT P.T.O. KIT FOR 31' & 36' AUGER
F7064	BELT P.T.O. KIT FOR 41' & 46' AUGER
F7065	BELT P.T.O. KIT FOR 51' AUGER

NOTE: CONVERSION KITS

IN ORDER TO CONVERT 8" DIRECT DRIVE AUGERS TO BELT DRIVE
YOU NEED ONE OF THE FOLLOWING KITS:

Y7066	CONVERSION KIT FOR 8" x 41' DIRECT DRIVE
Y7067	CONVERSION KIT FOR 8" x 46' DIRECT DRIVE
Y7068	CONVERSION KIT FOR 8" x 51' DIRECT DRIVE

NOTE: WE DO NOT RECOMMEND THE 8" x 51' BELT DRIVE AUGER.

ACCESSORIES AVAILABLE

7" FLEX SPOUT

8" FLEX SPOUT

BATTERY BOX

SHIPPING BUNDLES

FARM KING PORTABLE AUGERS

SIZE: 7" X 31' SINGLE BELT DRIVE AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F5006	BASIC AUGER, 7" X 22' (31', 36' & 41')
1 ONLY	F8001	EXTENSION AUGER, 7" X 9'
1 ONLY	F8020	UNDERCARRIAGE, 2" X 9'
1 ONLY	F8030	LIFT ARMS, 2" X 6'
1 ONLY	F8039	CRATE OF PARTS, 7" X 31'
1 ONLY	F0050	MOTOR MOUNT
1 ONLY	F7051	HANGER AND LEVELLING ROD, 36 1/2"
1 ONLY	F7071	INTAKE ASSEMBLY, 7" X 26"
1 ONLY	F7101	DRIVE LINE SHIELDS
2 ONLY	F7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 7" X 36' DOUBLE BELT DRIVE AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F5006	BASIC AUGER, 7" X 22' (31', 36' & 41')
1 ONLY	F8002	EXTENSION AUGER, 7" X 14'
1 ONLY	F8021	UNDERCARRIAGE, 2" X 10'8"
1 ONLY	F8031	LIFT ARMS, 2" X 7'
1 ONLY	F8042	CRATE OF PARTS, 7" X 36'
1 ONLY	F0050	MOTOR MOUNT
1 ONLY	F7051	HANGER AND LEVELLING ROD, 36 1/2"
1 ONLY	F7071	INTAKE ASSEMBLY, 7" X 26"
1 ONLY	F7102	DRIVE LINE SHIELDS
2 ONLY	F7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 7" X 41' DOUBLE BELT DRIVE AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F5006	BASIC AUGER, 7" X 22' (31', 36' & 41')
1 ONLY	F8003	EXTENSION AUGER, 7" X 19'
1 ONLY	F8026	UNDERCARRIAGE, 2" X 12'3"
1 ONLY	F8032	LIFT ARMS, 2" X 8'8"
1 ONLY	F8043	CRATE OF PARTS, 7" X 41'
1 ONLY	F0050	MOTOR MOUNT
1 ONLY	F7052	HANGER AND LEVELLING ROD, 44"
1 ONLY	F7071	INTAKE ASSEMBLY, 7" X 26"
1 ONLY	F7095	DRIVE LINE SHIELDS
2 ONLY	F7110	15" X 4.5" X 4 BOLT WHEELS

SHIPPING BUNDLES

FARM KING PORTABLE AUGERS

SIZE: 7" X 46' BELT-DRIVE PTO AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 7001	BASIC AUGER, 7" X 22' (46' & 51')
1 ONLY	F 8004	EXTENSION AUGER, 7" X 24'
1 ONLY	F 8024	UNDERCARRIAGE, 2 3/8" X 13'
1 ONLY	F 8034	LIFT ARMS, 2 1/2" X 10'4"
1 ONLY	F 8044	CRATE OF PARTS, 7" X 46'
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 7052	HANGER AND LEVELLING ROD, 44"
1 ONLY	F 7064	BELT-DRIVE PTO KIT, 41' & 46'
1 ONLY	F 7071	INTAKE ASSEMBLY, 7" X 26"
1 ONLY	F 7096	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 7" X 51' BELT-DRIVE PTO AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 7001	BASIC AUGER, 7" X 22' (46' & 51')
1 ONLY	F 8005	EXTENSION AUGER, 7" X 29'
1 ONLY	F 8025	UNDERCARRIAGE, 2 3/8" X 14'6"
1 ONLY	F 8035	LIFT ARMS, 2 1/2" X 12'
1 ONLY	F 8045	CRATE OF PARTS, 7" X 51'
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 7053	HANGER AND LEVELLING ROD, 51' (51"L.)
1 ONLY	F 7065	BELT-DRIVE PTO KIT, 51'
1 ONLY	F 7071	INTAKE ASSEMBLY, 7" X 26"
1 ONLY	F 7097	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SHIPPING BUNDLES

FARM KING PORTABLE AUGERS

SIZE: 7" x 31' BELT-DRIVE AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 5006	BASIC AUGER, 7" X 22' (31', 36' & 41')
1 ONLY	F 8001	EXTENSION AUGER, 7" X 9'
1 ONLY	F 8020	UNDERCARRIAGE, 2" X 9'
1 ONLY	F 8030	LIFT ARMS, 2" X 6'
1 ONLY	F 8039	CRATE OF PARTS, 7" X 31'
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 7051	HANGER AND LEVELLING ROD, 36 1/2"
1 ONLY	F 7063	BELT-DRIVE PTO KIT, 31' & 36'
1 ONLY	F 7071	INTAKE ASSEMBLY, 7" X 26"
1 ONLY	F 7101	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 7" X 36' BELT-DRIVE PTO AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 5006	BASIC AUGER, 7" X 22' (31', 36' & 41')
1 ONLY	F 8002	EXTENSION AUGER, 7" X 14'
1 ONLY	F 8021	UNDERCARRIAGE, 2" X 10'8"
1 ONLY	F 8031	LIFT ARMS, 2" X 7'
1 ONLY	F 8042	CRATE OF PARTS, 7" X 36'
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 7063	BELT-DRIVE PTO KIT, 31' & 36'
1 ONLY	F 7051	HANGER AND LEVELLING ROD, 36 1/2"
1 ONLY	F 7071	INTAKE ASSEMBLY, 7" X 26'
1 ONLY	F 7102	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 7" x 41' BELT-DRIVE PTO AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 5006	BASIC AUGER, 7" X 22' (31', 36' & 41')
1 ONLY	F 8003	EXTENSION AUGER, 7" X 19'
1 ONLY	F 8026	UNDERCARRIAGE, 2" X 12'3"
1 ONLY	F 8032	LIFT ARMS, 2" X 8'8"
1 ONLY	F 8043	CRATE OF PARTS, 7" X 41'
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 7052	HANGER AND LEVELLING ROD, 44"
1 ONLY	F 7064	BELT-DRIVE PTO KIT, 41' & 46'
1 ONLY	F 7071	INTAKE ASSEMBLY, 7" X 26"
1 ONLY	F 7095	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SHIPPING BUNDLES

FARM KING PORTABLE AUGERS

SIZE: 7" X 46' DOUBLE BELT DRIVE AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 7001	BASIC AUGER, 7" X 22' (46' & 51')
1 ONLY	F 8004	EXTENSION AUGER, 7" X 24'
1 ONLY	F 8024	UNDERCARRIAGE, 2 3/8" X 13'
1 ONLY	F 8034	LIFT ARMS, 2 1/2" X 10'4"
1 ONLY	F 8044	CRATE OF PARTS, 7" X 46'
1 ONLY	F 0050	MOTOR MOUNT
1 ONLY	F 7052	HANGER AND LEVELLING ROD, 44"
1 ONLY	F 7071	INTAKE ASSEMBLY, 7" X 26"
1 ONLY	F 7096	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 7" X 51' DOUBLE BELT DRIVE AUGER

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 7001	BASIC AUGER, 7" X 22' (46' & 51')
1 ONLY	F 8005	EXTENSION AUGER, 7" X 29'
1 ONLY	F 8025	UNDERCARRIAGE, 2 3/8" X 14'6"
1 ONLY	F 8035	LIFT ARMS, 2 1/2" X 12'
1 ONLY	F 8045	CRATE OF PARTS, 7" X 51'
1 ONLY	F 0050	MOTOR MOUNT
1 ONLY	F 7053	HANGER AND LEVELLING ROD, 51"
1 ONLY	F 7071	INTAKE ASSEMBLY, 7" X 26"
1 ONLY	F 7097	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SHIPPING BUNDLES

FARM KING PORTABLE AUGERS

SIZE: 8" X 41' DIRECT-DRIVE PTO AUGERS

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 5003	BASIC AUGER, 8" X 22' DIRECT PTO (41')
1 ONLY	F 7006	EXTENSION AUGER, 8" X 19' DIRECT DRIVE
1 ONLY	F 8027	UNDERCARRIAGE, 2 3/8" X 12'3"
1 ONLY	F 8033	LIFT ARMS, 2 3/8" X 8'8"
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 8062	CRATE OF PARTS, 8" X 41' DIRECT-DRIVE
1 ONLY	F 7072	INTAKE ASSEMBLY, 8" X 28"
1 ONLY	F 7098	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 8" X 46' DIRECT-DRIVE PTO AUGERS

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 7004	BASIC AUGER, 8" X 22' DIRECT PTO (46' & 51')
1 ONLY	F 7007	EXTENSION AUGER, 8" X 24' DIRECT-DRIVE
1 ONLY	F 8024	UNDERCARRIAGE, 2 3/8" X 13'
1 ONLY	F 8034	LIFT ARMS, 2 1/2" X 10'4"
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 8061	CRATE OF PARTS, 8" X 46' DIRECT-DRIVE
1 ONLY	F 7072	INTAKE ASSEMBLY, 8" X 28"
1 ONLY	F 7099	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 8" X 51' DIRECT-DRIVE PTO AUGERS

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 7004	BASIC AUGER, 8" X 22' DIRECT PTO (46' & 51')
1 ONLY	F 7008	EXTENSION AUGER, 8" X 29' DIRECT-DRIVE
1 ONLY	F 8025	UNDERCARRIAGE, 2 3/8" X 14'6"
1 ONLY	F 8035	LIFT ARMS, 2 1/2" X 12'
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 8060	CRATE OF PARTS, 8" X 51' DIRECT-DRIVE
1 ONLY	F 7072	INTAKE ASSEMBLY, 8" X 28"
1 ONLY	F 7100	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

F 1854	BOX-----)	CONVERSION KIT FOR 8" X 46'
F 1855	HANGER-----)	
F 1856	DRIVELINE-----)	
F 1851	BOX-----)	CONVERSION KIT FOR 8" X 41'
F 1852	HANGER-----)	
F 1853	DRIVELINE-----)	
F 1857-----)	CONVERSION KIT FOR 8" X 51'	
F 1858-----)		
F 1859-----)		

SHIPPING BUNDLES

FARM KING PORTABLE AUGERS

SIZE: 8" X 41' BELT-DRIVE PTO AUGERS

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 7003	BASIC AUGER, 8" X 22' BELT PTO (41')
1 ONLY	F 7018	EXTENSION AUGER, 8" X 19' BELT-DRIVE
1 ONLY	F 8027	UNDERCARRIAGE, 2 3/8" X 12'3"
1 ONLY	F 8033	LIFT ARMS, 2 3/8" X 8'8"
1 ONLY	F 8046	CRATE OF PARTS, 8" X 41' BELT-DRIVE
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 7052	HANGER AND LEVELLING ROD, 44"
1 ONLY	F 7064	BELT-DRIVE PTO KIT, 41' & 46'
1 ONLY	F 7072	INTAKE ASSEMBLY, 8" X 28"
1 ONLY	F 7095	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 8" X 46' BELT-DRIVE PTO AUGERS

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 7005	BASIC AUGER, 8" X 22' BELT PTO (46' & 51')
1 ONLY	F 7019	EXTENSION AUGER, 8" X 24' BELT-DRIVE
1 ONLY	F 8024	UNDERCARRIAGE, 2 3/8" X 13'
1 ONLY	F 8034	LIFT ARMS, 2 1/2" X 10'4"
1 ONLY	F 8047	CRATE OF PARTS, 8" X 46' BELT-DRIVE
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 7052	HANGER AND LEVELLING ROD, 44"
1 ONLY	F 7064	BELT-DRIVE PTO KIT, 41' & 46'
1 ONLY	F 7072	INTAKE ASSEMBLY, 8" X 28"
1 ONLY	F 7096	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS

SIZE: 8" X 51' BELT-DRIVE PTO AUGERS

<u>QUANTITY REQUIRED</u>	<u>BUNDLE NUMBER</u>	<u>DESCRIPTION</u>
1 ONLY	F 7005	BASIC AUGER, 8" X 22' BELT PTO (46' & 51')
1 ONLY	F 7020	EXTENSION AUGER, 8" X 29' BELT-DRIVE
1 ONLY	F 8025	UNDERCARRIAGE, 2 3/8" X 14'6"
1 ONLY	F 8035	LIFT ARMS, 2 1/2" X 12'
1 ONLY	F 8048	CRATE OF PARTS, 8" X 51' BELT-DRIVE
1 ONLY	F 0053	PTO SHAFT
1 ONLY	F 7053	HANGER AND LEVELLING ROD, 51"
1 ONLY	F 7065	BELT-DRIVE PTO KIT, 51'
1 ONLY	F 7072	INTAKE ASSEMBLY, 8" X 28"
1 ONLY	F 7097	DRIVE LINE SHIELDS
2 ONLY	F 7110	15" X 4.5" X 4 BOLT WHEELS
	F7115	OPEN INTAKE ASSEMBLY, 8"

Owner's Manual & Parts List

K2550 Basic Work Winch; 15.8:1 Gear Ratio; Automatic Brake

KX2550 Basic "KX" Winch, 15.8:1 Gear Ratio; Automatic Brake

INSTRUCTION FOR SAFER OPERATION

This winch is of a general purpose design and the load rating is based on an intermittent duty cycle. This winch is not designed to be a human hoist and should never be operated when there are persons positioned on or under the load being moved. The brake is actuated by turning the handle. The load-lok brake is designed to hold the load whenever the handle is released.

I. MOUNTING INSTRUCTIONS

1. Slide slot of handle onto the input shaft as shown in Figure 1 and fasten with 1/2-13 hex. locknut.
2. Bolt or weld the winch to a structure capable of supporting at least 5 times the load that the winch will pull. Fasten the winch with (4) 3/8 dia. bolts, S.A.E. Grade 5, (minimum strength). (Not supplied).





FIG.1



Do not remove or loosen this 1/2-13 hex. locknut (on brake side of winch) as it is a very important part of the load-lok brake system.

II. CABLE INSTRUCTIONS

1. Feed cable into the bottom of the drum using 5/16 dia. 7x19 galv. aircraft quality cable, max. 60 ft.
2. Have cable extend minimum of 2" past cable keeper.
3. All nuts for the cable clamp should be on the outside of the drum. See Figure 2.
4. Replace the cable if it is worn, frayed, or kinked.
5. Always be sure the cable is pulling straight off the winch and not contacting the frame or drum sides. Always prevent the cable from rubbing against fixed objects.




FIG.2

III. OPERATING PROCEDURE

A. TO PULL IN THE CABLE OR RAISE THE LOAD

1. The cable must be securely fastened to the object or the load and to the winch drum.
2. Be sure that the cable and hook are strong enough for the load and not damaged.
3. Turn the handle clockwise and listen for the clicking sound of the ratchet(s) for the load-lok brake.

B. TO LET OUT CABLE OR LOWER THE LOAD

1. Turn handle counterclockwise (no clicking sounds).
2. When cranking cable off the drum, some additional weight should be added at hook end to eliminate "bird nesting" of the cable still on the drum.





FIG.3

RECOMMENDED MAINTENANCE:

- APPLY AUTOMOTIVE TYPE GREASE TO BOTH THE PINION AND DRUM GEAR TEETH, AND TO THE O.D. OF DRUM BEARING, ITEM 44.
- APPLY A FEW DROPS OF AUTOMOTIVE ENGINE OIL TO RATCHET PAWL PIVOT(S), BUSHINGS, AND PINION THREADS.
- CHECK BRAKE DISCS, ITEM 17, FOR WEAR. IF LESS THAN 1/16 OF AN INCH THICK, CRACKED, OR BROKEN, IT SHOULD BE REPLACED.
- CHECK FOR PROPER RATCHET OPERATION AS FOLLOWS: WHEN CRANKING CABLE IN, A LOUD CLICKING SOUND SHOULD BE HEARD. WHEN CRANKING CABLE OUT, THERE IS NO CLICKING AND THE RATCHET PAWL(S) SHOULD BE FULLY ENGAGED INTO THE RATCHET GEAR TEETH.

REMEMBER WORN OUT PARTS CAUSE UNSAFE CONDITIONS

1. Do not get any oil or grease on the brake disc fibers.
2. Be sure that the cable on the winch is strong enough to support the load to be lifted. ALWAYS inspect the cable and hook before each use to make sure they are not damaged. Replace the cable if it is frayed or kinked. If the cable or hook breaks, the cable can act like a whip and can inflict serious injury to anyone in the path of the cable.
3. NEVER stand along side the winch cable, or guide the cable with your hands.
4. NEVER permit anyone on or under the load that is being pulled or lifted.
5. NEVER operate with wet or oily hands and ALWAYS use a firm grip on the handle.
6. NEVER leave a weight hanging by the winch while the winch is unattended, as unauthorized persons may attempt to operate the winch, thereby creating an unsafe condition.



ITEM	DESCRIPTION	KX2550	K2550	ITEM
1	Handle	2435S01	2461S01	1
2	Cable Clamp	Cable Keeper Kit 6017S01	Not Used	2
3	Locknut	Not Used	Cable Keeper Kit 5621S01	3
4	Bolt	Not Used	Cable Keeper Kit 5621S01	4
5	Cable Clamp	Not Used	Cable Keeper Kit 5621S01	5
6	Lockwasher	Not Used	Cable Keeper Kit 5621S01	6
7	Nut	Not Used	Cable Keeper Kit 5621S01	7
8	Input Shaft	Input Shaft	Input Shaft	8
9	Retaining Ring	Input Shaft	Input Shaft	9
10	Brake Disc	Input Shaft	Input Shaft	10
11	Ratchet Gear	Kit 1566S01	Kit 1565S01	11
12	Pinion Gear	Kit 1566S01	Kit 1565S01	12
13	Bushing	Kit 1566S01	Kit 1565S01	13
14	Insert	Kit 1566S01	Kit 1565S01	14
15	Spacer	Kit 1566S01	Kit 1565S01	15
16	Nut	Kit 1566S01	Kit 1565S01	16
17	Friction Disc	Kit 1578S00	Kit 1578S00	17
18	Bushing	Kit 1578S00	Kit 1578S00	18
19	Insert	Kit 1578S00	Kit 1578S00	19
20	Insert	Kit 1578S00	Kit 1578S00	20
21	Bushing	Kit 1578S00	Kit 1578S00	21
22	Washer	Kit 1578S00	Kit 1578S00	22
23	Intermediate Shaft	Kit 1578S00	Kit 1578S00	23
24	Rollpin	Kit 1578S00	Kit 1578S00	24
25	Woodruff Key	Kit 1578S00	Kit 1578S00	25
26	Gear	Kit 1578S00	Kit 1578S00	26
27	Nut	Kit 1578S00	Kit 1578S00	27
28	Spacer	Kit 1578S00	Kit 1578S00	28
29	Ratchet Pawl	Kit 1578S00	Kit 1578S00	29
30	Spring	Kit 1578S00	Kit 1578S00	30
31	Shoulder Bolt	Kit 1578S00	Kit 1578S00	31
32	Nut	Kit 1578S00	Kit 1578S00	32
33	Spacer	Kit 1578S00	Kit 1578S00	33
34	Ratchet Pawl	Kit 1578S00	Kit 1578S00	34
35	Spring	Kit 1578S00	Kit 1578S00	35
36	Spacer	Kit 1578S00	Kit 1578S00	36
37	Spacer	Kit 1578S00	Kit 1578S00	37
38	Support	Kit 1578S00	Kit 1578S00	38
39	Bolt	Kit 1578S00	Kit 1578S00	39
40	Cover	Kit 1578S00	Kit 1578S00	40
41	Drum Cover	Kit 1578S00	Kit 1578S00	41
42	Drum Bolt T-Grade 5	Kit 1578S00	Kit 1578S00	42
43	Locknut	Kit 1578S00	Kit 1578S00	43
44	Drum Spacer	Kit 1578S00	Kit 1578S00	44
45	Drum Assembly	Kit 1578S00	Kit 1578S00	45
46	Locknut	Kit 1578S00	Kit 1578S00	46
47	Frame Spacer	Kit 1578S00	Kit 1578S00	47
48	Bolt	Kit 1578S00	Kit 1578S00	48
49	Frame	Kit 1578S00	Kit 1578S00	49

* Std. Hardware - Purchase Locally
** Part Not Sold Separately

Replacement Parts Are Available From Your Dealer Or The Factory Use Genuine Fulton Parts

Please order by specifying:

Model Number:

Name of Part or Kit:

For special winch configuration, contact the Service Department.

FULTON MANUFACTURING CORPORATION
P.O. Box 19903
Milwaukee, Wisconsin 53219

LIMITED WARRANTY

All Fulton® hand winches are warranted to the original consumer purchaser to be free from defects in material and workmanship under normal use and service, ordinary wear and tear excepted, for a period of one (1) year from date of purchase as shown on purchaser's receipt.

Fulton will repair or replace, AT ITS OPTION AND FREE OF CHARGE, during the warranty period, any part which proves defective in material or workmanship, provided the product is returned to our factory for our examination. TRANSPORTATION CHARGES PREPAID at the address below. THIS WARRANTY IS LIMITED TO DEFECTIVE PARTS REPAIR AND/OR REPLACEMENT ONLY. LABOR CHARGES AND/OR DAMAGE INCURRED IN INSTALLATION, REPAIR OR REPLACEMENT AS WELL AS INCIDENTAL AND CONSEQUENTIAL DAMAGES CONNECTED THEREWITH ARE EXCLUDED.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Any damage to the hand winch, jack or stabilizer as a result of misuse, abuse, neglect, accident, improper installation, alteration, or repair (not our own), or any use contrary to our instructions, WILL VOID THE WARRANTY.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. In the event of a problem with warranty service or performance, you may be able to go to a small claims court, a state court, or federal district court.

FULTON

FULTON MANUFACTURING CORP.

P.O. BOX 19903 • MILWAUKEE, WISCONSIN 53219 • (414) 321-4810


a subsidiary of Masco Corporation Taylor, Michigan



LOOK OUT FOR **CHILDREN**.
TEACH YOUR CHILDREN SAFETY.
(INFORM THEM OF DANGERS AROUND MACHINES.)


MANUAL MUST BE READ AND
UNDERSTOOD BY **OPERATOR**.

TRANSPORT



EMBLEMS MUST BE VISIBLE.


ALWAYS MOVE EQUIPMENT IN
LOW OR DOWN POSITIONS
ESPECIALLY AROUND
POWER LINES.



NEVER LEAVE EQUIPMENT IN
RAISED POSITIONS.

SERVICE

SERVICE EQUIPMENT ONLY
WHEN **STOPPED** AND SECURELY
BLOCKED IF IN RAISED
POSITIONS.



KEEP ALL **GUARDS** AND **SHIELDS**
IN PLACE.

REPLACE DAMAGED OR WORN
PARTS. FRAYED CABLES AND
HOSES ARE DANGEROUS.



DO NOT CHANGE FACTORY SETTINGS.

KEEP **DECALS** CLEAN AND LEGIBLE.
(REPLACEMENTS NORMALLY AVAILABLE)



FARM KING ALLIED INC.

A John Buhler Company

WAREHOUSE LOCATIONS

MONCTON, NB
(506) 388-3008

EDMONTON, AB
(403) 962-6991

DORION, PQ
(514) 455-7946

WOODSTOCK, ON
(519) 539-0435

REGINA, SK
(306) 781-2300